

Modulating rotary actuator failsafe and extended functionalities for adjusting dampers in technical building installations and in laboratories

- Air damper size up to approx. 1.2 m²
- Torque motor 6 Nm
- Nominal voltage AC/DC 24 V
- Control modulating 0.5...10 V
- Position feedback 0.5...10 V
- Running time motor 4 s



Technical data			
- 1		10/00 04 14	
Electrical data	Nominal voltage	AC/DC 24 V	
	Nominal voltage frequency	50/60 Hz	
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V	
	Power consumption in operation	11 W	
	Power consumption in rest position	3 W	
	Power consumption for wire sizing	22 VA	
	Power consumption for wire sizing note	Imax 20 A @ 5 ms	
	Connection supply / control	Cable 1 m, 4 x 0.75 mm ²	
	Parallel operation	Yes (note the performance data)	
Functional data	Torque motor	6 Nm	
	Operating range Y	0.510 V	
	Input Impedance	100 kΩ	
	Position feedback U	0.510 V	
	Position feedback U note	Max. 0.5 mA	
	Setting fail-safe position	0100%, adjustable in increments of 10% (POP rotary knob on 0 corresponds to left end stop)	
	Position accuracy	±5%	
	Direction of motion motor	selectable with switch 0/1	
	Direction of motion note	Y = 0 V: At switch position 0 (ccw rotation) /	
		1 (cw rotation)	
	Direction of motion fail-safe	selectable with switch 0100%	
	Manual override	with push-button	
	Angle of rotation	Max. 95°	
	Angle of rotation note	can be limited on both sides with adjustable mechanical end stops	
	Minimum angle of rotation	Min. 30°	
	Running time motor	4 s / 90°	
	Running time fail-safe	4 s / 90°	
	Running time fail-safe note	<4 s @ 050°C	
	Adaptation setting range	manual (automatic on first power-up)	
	Sound power level, motor	60 dB(A)	
	Sound power level, fail-safe	60 dB(A)	
	Mechanical interface	Universal shaft clamp 826.7 mm	
	Position indication	Mechanically, pluggable	
Safety	Protection class IEC/EN	III Safety Extra-Low Voltage (SELV)	
	Protection class UL	UL Class 2 Supply	
	Degree of protection IEC/EN	IP54	
	Degree of protection NEMA/UL	NEMA 2	
	Enclosure	UL Enclosure Type 2	
	EMC	CE according to 2014/30/EU	
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14	
	Certification UL	cULus according to UL60730-1A, UL60730-2- 14 and CAN/CSA E60730-1:02	
	Certification UL note	The UL marking on the actuator depends on the production site, the device is UL-compliant in any case	
	Mode of operation	Type 1.AA	
	Pated impulse voltage cumply / central	0.0 1/1	

Rated impulse voltage supply / control

0.8 kV

Very fast running rotary actuator, modulating, AC/DC 24 V, 6 Nm, Running time motor 4 s



Technical data Safety Control pollution degree 3 -30...50°C Ambient temperature Storage temperature -40...80°C Ambient humidity Max. 95% r.H., non-condensing Servicing maintenance-free Weight Weight 1.4 kg **Terms** POP = Power off position / fail-safe position Abbreviations PF = Power fail delay time / bridging time

Safety notes



- The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation
 or aggressive gases interfere directly with the actuator and that is ensured that the
 ambient conditions remain at any time within the thresholds according to the data
 sheet.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- · Cables must not be removed from the device.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation site and the ventilation conditions must be observed.
- Self adaption is necessary when the system is commissioned and after each adjustment of the angle of rotation (press the adaption push-button once).
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product features

Mode of operation

The actuator moves the damper to the desired operating position at the same time as the integrated capacitors are charged. Interrupting the supply voltage causes the damper to be rotated back into the fail-safe position by means of stored electrical energy.

The actuator is connected with a standard modulating signal of 0...10 V and drives to the position defined by the positioning signal. Measuring voltage U serves for the electrical display of the damper position 0.5...100% and as a slave control signal for other actuators.



Product features


Pre-charging time (start up)

The capacitor actuators require a pre-charging time. This time is used for charging the capacitors up to a usable voltage level. This ensures that, in the event of a power failure, the actuator can move at any time from its current position into the preset fail-safe position.

The duration of the pre-charging time depends mainly on following factors:

- Duration of the power failure
- PF delay time (bridging time)

Typical pre-charging times



[[]d] = Electricity interruption in days [s] = Pre-charging time in seconds PF[s] = Bridging time

Delivery condition (capacitors)

The actuator is completely discharged after delivery from the factory, which is why the actuator requires approximately 15 s pre-charging time before initial commissioning in order to bring the capacitors up to the required voltage level.

Simple direct mounting

Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti-rotation device to prevent the actuator from rotating.

Manual override

Manual control with push-button possible - temporary. The gear is disengaged and the actuator decoupled for as long as the button is pressed.

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops. A minimum permissible angle of rotation of 30° must be allowed for.

High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out an adaption, which is when the operating range and position feedback adjust themselves to the mechanical setting range.

The detection of the mechanical end stops enables a gentle approach to the end positions, thus protecting the actuator mechanics.

The actuator then moves into the position defined by the positioning signal.

Setting direction of rotation

When actuated, the direction of the rotation switch changes the running direction in normal operation. The direction of the rotation switch has no influence on the fail-safe position which has been set.

Setting fail-safe position (POP)

The rotary knob fail-safe position can be used to adjust the desired fail-safe position 0...100% in 10% increments.

The rotary knob refers only to the adapted angle of rotation range 30°...95°. No set min. or max. values are observed.

In the event of a power failure, the actuator will move into the selected fail-safe position, taking into account the bridging time that has been set.

Adaption and synchronisation

An adaption can be triggered manually by pressing the "Adaption" button. Both mechanical end stops are detected during the adaption (entire setting range).



Accessories

Electrical accessories

Description	Туре
Auxiliary switch 1 x SPDT add-on	S1A
Auxiliary switch 2 x SPDT add-on	S2A
Auxiliary switch 2 x SPDT add-on, grau	S2A/300 GR
Auxiliary switch 2 x SPDT add-on, grau	S2A/500 GR
Feedback potentiometer 140 Ω add-on	P140A
Feedback potentiometer 140 Ω add-on, grau	P140A GR
Feedback potentiometer 200 Ω add-on	P200A
Feedback potentiometer 500 Ω add-on	P500A
Feedback potentiometer 500 Ω add-on, grau	P500A GR
Feedback potentiometer 1 k Ω add-on	P1000A
Feedback potentiometer 1 k Ω add-on, grau	P1000A GR
Feedback potentiometer 2.8 k Ω add-on	P2800A
Feedback potentiometer 2.8 kΩ add-on, grau	P2800A GR
Feedback potentiometer 5 k Ω add-on	P5000A
Feedback potentiometer 5 k Ω add-on, grau	P5000A GR
Feedback potentiometer 10 kΩ add-on	P10000A
Feedback potentiometer 10 kΩ add-on, grau	P10000A GR
Adapter for auxiliary switch and feedback potentiometer	Z-SPA
Signal converter voltage/current 100 kΩ Supply AC/DC 24 V	Z-UIC
Range controller for wall mounting	SBG24
Positioner for wall mounting	SGA24
Positioner for built-in mounting	SGE24
Positioner for front-panel mounting	SGF24
Positioner for wall mounting	CRP24-B1
Description	Туре
Actuator arm for standard shaft clamp (one-sided)	AH-25
Shaft extension 240 mm Ø20 mm for damper shaft Ø 822.7 mm	AV8-25
Mounting kit for linkage eneration for flat installation	ZG_NMA

Mechanical accessories

	71	
Actuator arm for standard shaft clamp (one-sided)	AH-25	
Shaft extension 240 mm Ø20 mm for damper shaft Ø 822.7 mm	AV8-25	
Mounting kit for linkage operation for flat installation	ZG-NMA	

^{*} Adapter Z-SPA

It is imperative that this adapter will be ordered if an auxiliary switch or a feedback potentiometer is required.

Electrical installation




Notes

- · Connection via safety isolating transformer.
- Parallel connection of other actuators possible. Observe the performance data.

Wiring diagrams

Parallel operation




Notes

- A maximum of eight actuators can be connected in parallel.
- · Parallel operation is permitted only on non-connected axes.
- Do not fail to observe performance data with parallel operation.



Operating controls and indicators




- 1 Direction of rotation switch
- 2 Cover, POP button
- 3 POP button
- 4 Scale for manual adjustment
- 6 (no function)
- 7 Disengagement button

LED displays 8 yellow 9 green		Meaning / function	
Off	On	Operation OK / without fault	
Off	Flashing	POP function active	
On	Off	Fault	
Off	Off	Not in operation	
On	On	Adaptation procedure running	

Press button: Triggers angle of rotation adaption, followed by standard operation

Setting emergency setting position (POP)





Dimensions [mm]

Spindle length





Clamping range

	<u>OI</u>		$\bigcirc $
	826.7	≥8	≤26.7
*	820	≥8	≤20

*Option: Shaft clamp mounted below: If an auxiliary switch or a feedback potentiometer is used the adapter Z-SPA is required.

Dimensional drawings





6