


FTO1202-Z1


en	Zone indication field	pt	Campo de indicação da zona
de	Gruppenanzeigefeld		
fr	Champ d'indication de zone		
es	Campo de indicación de zona		
it	Campo indicazione zona		
nl	Groepenindicatie paneel		



en Installation
de Montage
fr Montage
es Montaje
it Montaggio
nl Montage

pt Instalação






FTO1202-Z1
 S54400-B119-A1





9	en	Test the system
	de	Testen Sie das System
	fr	Testez le système
	es	Pruebe el sistema
	it	Testare il sistema
	nl	Test het systeem
	pt	Teste ao sistema

en	You will find more information in document A6V10393190
de	Weitere Informationen finden Sie im Dokument A6V10393190
fr	Pour de plus amples informations, se référer au document A6V10393190
es	Para más información al respecto, consulte el documento A6V10393190
it	Per ulteriori informazioni si rimanda al documento A6V10393190
nl	Meer informatie kunt u vinden in het inbedrijfsteldocument A6V10393190
pt	Para mais informações, consulte o documento A6V10393190

www.siemens.com/buildingtechnologies